

# Recommended DROP ON RHINO TRED Installation



**During install and 72 hour after (minimum cure time). Stairwell must keep 50 Degrees Fahrenheit or higher. This is the minimum install and cure time temperature.**

- 1** Prior to application of adhesive. Surface(s) to be dry, free of dust and debris. Using a clean cotton cloth, with solvent, wipe surface(s) where adhesive is to be applied.
- 2** At the bottom side of tread. At each plugged hexagon. Apply 1/4" thick adhesive, the size of a quarter.
- 3** Gently set the tread on to the metal flat pan. Centered between stair stringers. Base of tread is not to overhang nosing of metal flat pan.  
Note: Installation should begin from top of risers to prevent stepping on treads during curing process
- 4** Press down firmly across the tread to allow adhesive to expand across the flat pan.
- 5** Allow a minimum of 72 hours for adhesive cure time. Do not walk on Rhino Tred.

Page 1 of 1

**NRT**  
**NATIONAL**  
**REDI-TREAD™**

1005 COMMERCE CT.,  
SILVERTON, OR 97381

503-362-5068  
SALES@NATIONALREDITREAD.COM  
NATIONALREDITREAD.COM



MADE IN THE  
**USA**